

Portable pressure hand-held shower/eye wash

EWP-106



Description

- Notes: The water stored in the tank needs to be replaced regularly, and the replacement period is 7 days
- Application: widely used in dust-free workshops, petroleum, chemical, pharmaceutical, fire fighting and other places.

Specifications

Model	EWP-106
Material	polyethylene (PE)
Function	shower + eye wash
Features	removable trolley
Volume	12L
Working pressure	0.2 ~ 0.4Mpa
Usage time	≥ 15min
Water usage temperature	0°C ~ 40°C

Portable pressure hand-held shower/eye wash

EWP-107



Description

- It has a mobile wheel and a water storage tank, free of pipeline installation, and the length of the rod can be adjusted according to the height of the human body.
- Enlarged the water injection port for easy water injection, and there are 2 filters
- The handle of the eye wash switch valve imitates the human hand shape design, with good hand feeling and flexible operation. Can be hung on the rack when not in use.
- Special charger, using intelligent three-stage charging (constant current / constant voltage / maintenance), with short circuit / over current / reverse connection protection function, The charger indicator shows: red-charging, green-full / standby
- 5. Notes: The water stored in the tank needs to be replaced regularly, and the replacement period is 7 days

Specifications

Model	EWP-107
Material	polyethylene (PE)
Function	shower + eye wash
Features	rechargeable mobile
Volume	20L
Working pressure	0.2 ~ 0.4Mpa
Usage time	≥ 15min
Water usage temperature	0°C ~ 40°C